



Ultrasonic Cleaning Solution Concentrate Ammonia and Phosphate-Free

Description

Chem-Crest General Purpose Cleaner 25 is a general purpose non-ammoniated ultrasonic cleaning solution. It is aqueous, heavy duty and biodegradable. It is a caustic-free alkaline cleaner.

Substrate Compatibility

Chem-Crest General Purpose Cleaner 25 is compatible with aluminum and magnesium, stainless steel, various medical and dental equipment and jewelry, glass, plastics, ceramics, copper and brass.

Typical Contaminants Removed

Chem-Crest General Purpose Cleaner 25 in Crest Ultrasonic Cleaning Systems provides rapid, effective and efficient removal of various surface contaminants such as: light oils, dried blood, grease, fingerprints and particulates.

Operating Concentration

Dilute 1 to 10. Typical cleaning time is 1-5 minutes at temperatures of 140° to 180°F. Rinse with water. Product rinses quickly and easily.

Storage

Avoid freezing conditions.

Disposal Methods

Chem-Crest General Purpose Cleaner 25 is non-hazardous and biodegradable, however it must be disposed of in accordance with Federal, State and Local Government regulations.

Safety Precautions

See Material Safety Data Sheet.

Availability

Chem-Crest General Purpose Cleaner is available in cases of 16 x 1 pints, 8x1 quarts, 4x1 gallons and 5 gallon containers.

Physical Data

Flash Point: None
Specific Gravity: 1.09
pH: 10% solution 10.0+/-0.5
Solubility in Water: Complete
Volatiles: N/A

**These values do not constitute specifications*

Disclaimer: All statements, technical information and recommendation contained herein are based on tests or other information available to us which we believe to be reliable, but the accuracy or completeness thereof is not guaranteed and are made without representation or warranty. They are presented for your own investigation and verification. Products discussed are sold without warranty, expressed or implied, in law or fact and upon the condition that purchasers make their own tests to determine the suitability of such products to their particular purpose. We shall not be liable for any injury, loss or damage direct or consequential, arising out of use or the inability to use the product. It is the user's obligation and responsibility to determine that any use of the product or the information may infringe on patent rights.

